



# Pascal

Cartridge filtration system for dry dusts and smokes



## Pasca

The new Pascal filter series are designed for the filtration of dust and smoke deriving from many machining processes.

The filtration module has specially been conceived for the industrial sector, where its important features lie in sturdiness, reliability and easiness of running and maintenance.

It is available in 3 sizes with flow rates ranging from 3.000 to 9.000 m<sup>3</sup>/h and with increasing filtration efficiency rates to reach 99,97%.




LOSMA grants that every single system is tested through strict control procedures. Every unit is provided with a qualitative and functional test certificate.





## Working principles



- The air entry section, which connects the piping to the filter, consists in a large section which serves as a calming chamber (A).
- The following area consists of a chamber which houses the filter elements, cartridge with folds (B) with a high filtration surface, with F9 efficiency of 95%, withholding the finer impurities.
- These cartridges are kept in perfect conditions from a programmable electronic cleaning system using compressed air (C) for counter-washing, which monitors continuously ΔP and manage sequentially the opening of electro-valves and the consequent cleaning cycles conserving
- compressed air consumption, contained in the storage reservoir. The program controller is equipped with a visual display for the visualization of main functionalities and the alarm limit planning.
- The horizontal positioning of cartridges allows fast and quick maintenance, access to the filtration chamber is possible through a hinged door. Filter removal is easy, quick and clean, because the dirty chamber is separated from the clean section by a panel which also serves as a support structure for the filter elements. Dust is collected in a large tank (D), which can easily be moved with mechanical lift.

### Plus



#### **VERSATILITY AND MODULARITY**

The use of filters with increasing filtration efficiency rate allows the implementation of Pascal in all modern mechanical machining, from the more simple to heavy duty operations. The 3 different available versions and relative suction power of Pascal enable to choose a solution which is always relevant to specific requirements without energy waste for oversized systems or, on the contrary, for systems which are not adequately dimensioned.




## PROGRAMMABLE ELECTRONIC SYSTEM

Permits the cleaning in counter-washing of cartridges using compressed air. It monitors continuously the  $\Delta P$  and manages the sequential opening of electro-valves and the cleaning cycles. In this way the system economize the compressed air contained into the tank. It has a digital display to visualize the main functions and setting the alarm limit.



#### **GREAT SUCTION POWER**

the use of high efficiency centrifugal fans and the high flow rates generated enable the Pascal series to be implemented for suction and filtration of large machine tools and for centralized systems.




#### **FAST AND EASY MAINTENANCE**

Access to the filtration section is very easy and quick, without having to unscrew or disassemble anything. Simply unlock and open the hinged door to access the filters, which can easily be extracted and replaced in a short time.



## Technical data



MODELS			Dim	Open door dimensions	Weight				
	Α	В	н	H1	H2	Н3	H4	B1	kg
PASCAL 3000	1000	1420	1940	2135	2320	2650	2870	2080	430
PASCAL 4000	1200	1470	1940	2180	2320	2650	2870	2400	440
PASCAL 5000	1200	1470	1940	2195	2320	2650	2870	2440	445
PASCAL 6000 (*)	1500	1520	2450	2620	3100	3430	3650	2700	680
PASCAL 7000 (*)	1500	1520	2450	2645	3100	3430	3650	2700	710
PASCAL 9000 (*)	1500	1520	2450	2755	3100	3430	3650	2700	820

<sup>\*</sup> With external electrical panel

MODELO	Max air flow*	Head (mm H <sub>a</sub> O)	Power (kW) 50 (Hz) / 60 (Hz)	Cartridge number	Filtration surface (m^2)	Noise level	RPM (rpm)		Tank	Kg activated N. cartridge	
MODELS	50 (Hz) / 60 (Hz)	' ' '				(dBa)**	50 (Hz)	60 (Hz)	capacity liter	carbons total	activated carbons
Pascal 3000	3000	180	2,2	3	36	<80	2850	3420	135	64	4
Pascal 4000	4000	160	3	4	48	<80	2900	3480	205	80	4
Pascal 5000	5000	240	4	5	60	<80	2910	3490	205	80	5
Pascal 6000 (*)	6000	180	5.5	6	72	<80	2890	3470	300	128	5
Pascal 7000 (*)	7000	280	7.5	7	84	<80	2890	3470	300	128	8
Pascal 9000 (*)	9000	170	11	9	108	<80	2930	3520	300	128	8

<sup>\*</sup> With external electrical panel
\*\* With soundproof box

## **Optional**

#### **Absolute filter H13**


To obtain a very high filtration level, 99,97% according to norm EN 1822. Particularly suitable for micro-mists and smokes.

#### **Carbon filter**

Activated carbons for removal of odors from previously filtered air.



## Installations






## Pascal-M



## Working principles



- 1 The air entry section, which connects the piping or the suction arm (optional), consists in a large section which serves as a calming chamber (A).
- The following area consists of a chamber which houses the filter elements, cartridge with folds (B) with a high filtration surface, with F9 efficiency of 95%, withholding the finer impurities.
- These cartridges are kept in perfect conditions from a cleaning system (optional) using compressed air (C), consisting in a Timer which manage the opening of the

- electro-valves positioned on the storage reservoir and the cleaning cycles.
- The horizontal positioning of cartridges allows a fast access and a quick maintenance, access to the filtration chamber is possible through a hinged door. Filter removal is easy, quick and clean, because the dirty chamber is separated from the clean section by a panel which also serves as a support structure for the filter elements. Dusts are collected in a collection tank (D), which can easily be removed and emptied. The filtration group is equipped with a trolley in order to be moved into the workshop.



### Plus



#### **VERSATILITY AND MANEUVERABILITY**

Pascal-M is available in two versions with different flow rates and can be equipped with different post-filtration accessories and an articulated arm. It is mounted on a trolley allowing an easy transport.



#### LONG LASTING FILTERS

The wide filtration surface used and the automatic cleaning system (optional) grants long lasting filters and saving for spare parts and maintenance management.



#### **GREAT SUCTION POWER**


The use of high efficiency centrifugal fans allows Pascal-M to generate great suction powers with reduced energy consumption.




#### **FAST AND EASY MAINTENANCE**

Access to the filtration section is very easy and quick, without having to unscrew or disassemble anything. Simply unlock and open the hinged door to access the filters, which can easily be extracted and replaced in a short time.

## Technical data





MODELS			Dim	Open door dimensions	Weight				
	Α	В	Н	H1	H2	Н3	H4	B1	kg
PASCAL 1500 M	800	1200	1200	1650	1700	2030	2250	1655	210
PASCAL 2500 M	800	1200	1200	1700	1750	2030	2250	1655	225

MODELS	Max air flow (m³/h)	Head (mm H <sub>2</sub> O)	Power (kW)	Cartridge number	surface	Noise level (dBa)**		(rpm)	capacity	carbons	N. cartridges activated
	50 (Hz) / 60 (Hz)		50 (Hz) / 60 (Hz)		(m^2)	(uba)	50 (Hz)	60 (Hz)	liter	total	carbons
PASCAL 1500 M	1500	123	1.1	1	10	<80	2840	3410	30	32	2
PASCAL 2500 M	2500	101	1.5	2	20	<80	2840	3410	30	32	2

<sup>\*\*</sup> With soundproof box